



Advanced Communications Australia Pty Ltd Ph: 02 4903 6666 Fx: 02 4903 6677 PO Box 269 Hunter Region MC NSW 2310 E: sales@advcom.com.au www.advcom.com.au

How to Adjust the Time for Daylight Savings on a

Panasonic - TDA30/ TDA100/ TDA200

The time can be changed from system manager phone *(generally the reception phone)*

- Do not lift the handset
- Press the "PROGRAM" button
- Dial * # 1234
- Dial 0 0 0
- "ENTER" + "NEXT"
- Change the time (using keypad)
- Press the AUTODIAL /STORE button
- Lift handset & hang up

